

TESTING BALLOT DEFLECTOR

Remove memory card from machine.

Place Accu-Vote machine on ballot box (plug in).

Holding the yes and no button, turn machine on.

Display should read:

- Diagnostics Test Mode
- Set System Clock

Press the 'NO' button until the display reads:

- Test Ballot Deflector

Make sure the machine is inserted properly on the ballot box.

- Press the 'YES' button

At this point the deflector should be moving side to side.

You can check this by lifting the top of the ballot box up and checking
(**CAUTION:** It is heavy, hold on to the machine)

Deflector angle should be about even on both sides.

The deflector should turn back and forth opening the right bin, then the left.

If not, please call LHS for further assistance.

Turn machine off when test is finished.



LHS Associates, Inc.
13 Branch Street
Methuen, Massachusetts 01844

Phone: 1.888.547.8683
Fax: 1.978.687.3670 / 1.978.687.9962